

Additional Instructions

- Drivers **MUST** switch off their engine when in position.
- If vehicle on uneven ground, wheel chocks must be used.
- Drivers are not permitted to use Hub Le Bas lifting equipment.
- Drivers **MUST** stay with their vehicle, do not wonder round the site.
- When possible battens should be used to separate loads.
- Drivers <u>MUST</u> follow instructions from Hub Le Bas employees regarding safe loading and unloading of vehicles.
- When available, access platforms must be used when accessing the rear of vehicle.
- Drivers must leave the danger area when loads being moved.
- When using slings, they should not be tangled around goods or other slings. This can cause sudden movement of other goods.

All unsafe loads will be returned to the Supplier.